

KODAK CHERISH C220

SMART BABY MONITOR

Quick Start Guide

For full explanation of all features and instructions, please refer to the Setup & Installation Guide.



(I) Setup in App

1. Download the **KODAK Smart Home** app from the APP STORE (iOS) or GOOGLE PLAY Store(Android).
2. Create or login to your account.
3. Add the **KODAK CHERISH C220** Baby Monitor to your **KODAK Smart Home** app.
4. Follow the instructions to set up your Baby Monitor.
5. Pairing in progress. Wait until you hear the message "Setup Completed."
6. Once paired, test your Baby Monitor. Move your router if necessary.

(II) Pairing between the Baby Unit and the Parent Unit

The Baby Unit comes pre-registered to the Parent Unit. Simply connect the power supply for both the Baby Unit and the Parent Unit to start using.

1. Connect the small end of the power adapter to the Baby Unit and the other end to the electrical outlet. Only use the adapter supplied (5V DC/1500mA). Ensure the ON/OFF switch is in the "ON" position.
2. Connect the small end of the power adapter to the Parent Unit and the other end to the electrical outlet. Only use the adapter supplied (5V DC/1500mA).



WARNING:

STRANGULATION HAZARD-Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3ft (1m) away) from the crib. Do not use with an extension cord. Only use the AC Adapters provided.

(III) Basic Operations

Baby Unit

Slide to the **ON** or **OFF** position to switch ON or OFF the unit.

Parent Unit



Menu Key

Press to enter/exit the menu mode



Return Key

Press to return to the previous page



Video Key

Press to turn on/off the LCD display



Up Key

Press to scroll /pan up



Down Key

Press to scroll /pan down



OK Key

Press to confirm

Power Key

Press to turn on/off the device

Talk Key

Press and hold to speak to your baby

Left Key

Press to scroll/pan left

Right Key

Press to scroll/pan right

KODAK Smart Home App Icons



Menu

Press to show/hide the mini menu



Mute/Unmute

Press to toggle between mute/unmute



Talk

Press this to talk to your baby




Screenshot

Press this to take a snapshot of the screen



Record a Video

Press this to record video



Melody

Press to play music for your baby

Zoom in/out

Press to zoom in/out the screen

Dashboard

Tap here to view all your connected devices

Video Gallery

Tap here to view your recorded footages

Timeline

Press here check the history of your devices

(IV) General Information

If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide at: <https://kodaksmarthome.com/support/userguides>
2. Contact customer service at: support@kodaksmarthome.com



The Kodak trademark, logo and trade dress are used under license from Kodak.