



### Quick Start Guide

For full explanation of all features and instructions, please refer to the Setup & Installation Guide.




#### (I) Add As An Additional Camera (for C220,C225,C520,C525)

1. Press "☰" on the Parent Unit for the menu bar.
2. Press "▲" or "▼" button to select , then "OK" to proceed to the next step.
3. Press "⊕" to add camera, then "OK" to proceed.
4. Press the "◀" button or "▶" button to select the desired camera number. (e.g: ) Press "OK" to add a camera.
5. You will then see a sign "📷" to indicate you to press and hold the pair button of the baby unit until you hear the beep from the Baby Unit. After that, the Parent Unit will find the camera, pair and get the video from the camera.

#### (II) Switch on the Baby Unit

Slide to the **ON** or **OFF** position to switch ON or OFF the unit.



C125

On/Off Switch



C120

#### **WARNING:**

**STRANGULATION HAZARD**-Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3ft (1m) away) from the crib. Do not use with an extension cord. Only use the AC Adapters provided.











### (III) Setup in App

1. Download the **KODAK Smart Home** app from the APP STORE (iOS) or GOOGLE PLAY Store(Android).
2. Create or login to your account.
3. Add the **KODAK CHERISH** Baby Unit to your **KODAK Smart Home** app.
4. Follow the instructions to set up your Baby Unit.
5. Pairing in progress. Wait until you hear the message "Setup Completed."
6. Once paired, test your Baby Unit. Move your router if necessary.

### (IV) Basic Operations

#### KODAK Smart Home App (Dashboard)

|   |  |  |
|---|--|--|
|  <b>Dashboard</b><br>Tap here to view all your connected devices   |  | <b>Hints</b> <br>Tap here for instruction of the app        |
|  <b>Video Gallery</b><br>Tap here to view your recorded footages  |  | <b>Add New Device</b> <br>Press this to add a new device   |
|  <b>Timeline</b><br>Press here check the history of your devices |  | <b>Camera Settings</b> <br>Press here for camera settings |
|  <b>Side Menu</b><br>Tap this to navigate more features          |  |  |

### (V) General Information

#### If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide at: <https://kodaksmarthome.com/support/userguides>
2. Contact customer service at: [support@kodaksmarthome.com](mailto:support@kodaksmarthome.com)



The Kodak trademark, logo and trade dress are used under license from Kodak.